



Iridium 9505A Quick Guide

Making a Test Call

1. Make sure you are **outside with an open view of the sky**, away from any obstructions.
2. Once **outside**, fully extend the antenna. Hold the on/off button for **5sec**. Make sure the antenna is straight at all times.
3. Once the phone says **registered** then **Iridium** dial "00" then dial country code (*Canada/US are "1"*) & number.
4. Press the OK button to place the call, and **press and hold the OK** button to end the call.



Your Iridium Phone Number

Calling to a Landline or Cellphone


1. Hold the "0" key until the "+" symbol appears, then dial **Country Code**, and rest of phone number.
2. Press **green button**. (talk)
3. Press **red button** to end.

Calling another Iridium phone


1. Dial 8816 - XXXX - XXXX

Receiving calls on your phone

1. **Caller** first dials:
1-480-768-2500
2. When prompted enter the **Iridium phone number**. (below)
3. **Wait** to be connected.



Use your Iridium phone with the **antenna extended** in an open area where the antenna has an **unobstructed 360° view of the sky**.



Avoid using your Iridium phone near **large buildings, trees or mountains** as these can obstruct line of sight with the satellites.

Sending a Text Message from the Iridium Phone

1. Ensure you are **outside** and have a **clear view of the sky**.
2. Press the **Message Key**
3. Using the arrow keys, scroll to **Message Editor** and press the **OK Key**.
4. Enter your message and press the **OK Key**.
5. **Follow** the on-screen prompts to send text message.

Sending a Text Message to the Iridium Phone

1. Have the person go to: **messaging.iridium.com**
2. In the form, enter the 12 digit sat phone number **without any dashes**.
3. Enter a reply **email** and your **message**.
4. Solve the **CAPTCHA**
5. Click **Send Message**.

Checking your Voicemail

1. Press the **Message** key.
2. Press the **OK** key to call Voicemail.
3. When prompted enter your **Iridium phone number** and password
4. For a password, enter "**9999**" or the **last seven (7) digits** of your Iridium Phone Number.

Scan to download
PDF copy ----->

